




My Collector Bag Won't Fold Down Properly.

Please refer to the steps below for instructions on how to fold your Collector Bag for storage.

For our fastest service during our peak seasons, please send a note to support@woodlandpowerproducts.com and we will be in touch within 1 business day or, you can contact us at our main line 888-531-7253 and at the prompt, please press 2 for technical support.


Folding the Collector Bag.



Remove the Top Brace.

1. Start with your Cyclone Rake fully assembled.


- Remove the top brace and place it inside the collector bag laying flat.



Pull the side linkage toward you.

2. Release the side links.


- Starting at either side, release one side link by sliding the slider bracket up and **PULLING THE LINK ELBOW TOWARD YOU** so it points to the outside of the frame.



Fold down one side.

3. Position the bag collar.

- Push the bag collar out of the way and push the aluminum side tube all the way down until the first side lies flat on the frame.
- Release other side linkage, once again, pulling the elbow towards the outside of the frame.



Fold down other side.

4. Position the side tube.

- Fold the side tube all the way down, you may have to adjust the bag collar so it lies flat as you push the side of the collector down.
- Secure with the green shock cord.

Thanks for being a Cyclone Rake customer and we hope this troubleshooting guide has helped resolve your issue!

WOODLAND POWER PRODUCTS, INC.

72 Acton Street, West Haven, Connecticut 06516

©2020, Woodland Power Products, Inc.