

Follow the instructions below to replace the Fabric Bag on your SPS-10.


TOOLS YOU'LL NEED: Phillips head and Flat head screwdrivers



1. Lay the fabric bag onto a flat surface with the back of the bag and the lip of the metal frame on top.



2. Remove the screws with the Phillips head screw driver.




3. Remove the T-nuts with the flat head screwdriver. Then remove the old fabric bag from the frame.



4. Lay the new fabric bag down on the flat surface with the back of the bag on top. Then, insert the metal frame with the lip of the frame on top making sure the holes and grommets line up.



5. Insert a T-nut into one of the grommets on the outside of the fabric bag. Then, from the inside of the bag, secure it to the frame with a screw. Repeat for all of the other T-nuts and screws. Be careful not to overtighten as it may damage the grommets in the bag.



NOTE: The back of the bag will have a tapered seam.

That's it! Your new Fabric Collector Bag is installed!

WOODLAND POWER PRODUCTS, INC.

72 Acton Street, West Haven, Connecticut 06516

www.CycloneRake.com

©2023, Woodland Power Products, Inc.

TOLL-FREE 1-(888)-531-RAKE

12-06-005 F23